

## Extended TX modification Yaesu FT-2000

**Author:** PD5DJ

Hi All

This modification is to extend the frequency range of the Yaesu FT-2000.

Frequency Range RX/TX: 1.8-30MHz, 50-54Mhz.

First of all, Turn off the mainswitch at the back and unplug all cables from the transceiver before starting to modify the radio..


1. Turn the transceiver upside down, so that the bottom cover up will be facing upwards and the front panel facing towards you.
2. Unscrew the bottom cover. 3 big screws on each side of the radio, and some little ones at the bottom. (no need to remove the 4 feet)
3. Remove the bottom cover, you will see another cover fixed with 15 screws.. See picture below



4. Unscrew the blank cover with the 15 screws.
5. When the cover removed, locate the JP30XX jumper section at the front-left (surrounded with yellow marking) See picture below



6. Locate location 04, solder this jumper with just a solder blob. See picture below



7. Reassemble the radio, when done plug in all cables. And turn on the mainswitch at the back.

8. Press and hold the [FAST] + [LOCK] buttons when turning on the radio, this will cause a full reset of the radio, but will initialize the radio for wideband TX.

9. Finished! You should now be able transmit through the whole frequency range of 1.8-30MHz, 50-54Mhz.

Good Luck! Bj+??rn de PD5DJ

This article is printed with permission from mods.dk the 02 Jul 2019. This printed article must only be used for non-commercial purposes; this is only for private use.

© Copyright mods.dk 1996 - 2019